

# 2022 PORTAPUMP JR PARTS

KEY	PART NO.	DESCRIPTION	NEED
1	PP-JR-GBT11674	HOUSING BOLT KIT- 8 BOLTS	1
2	PP-JR-L1102A01	SHAFT COLLAR	1
3	PP-JR-L1102A03	IMPELLER	1
4	PP-JR-L1102A02	INTERMITTENT COLLAR	1
5	PP-JR-L1102A04	VOLUTE	1
6	PP-JR-L1102S02	9 TOOTH SPLINE SHAFT ADAPTER	1
	PP-JR-L1102502-2	SQUARE SPLINE ADAPTER	1
7	PP-JR-GBT276	BEARING	2
8	PP-JR-L1102S01	SHAFT	1
9	PP-JR-GBT98771	LIP SEAL	1
10	PP-JR-L1102R0-345	DISCHARGE KIT: GASKET, MALE HOSE BARB, WING NUT	1
11	PP-JR-L1102R0-12	INTAKE KIT: STRAINER AND ADAPTER	1
*	PP-JR103	WIRE MESH SCREEN AND CLAMP	1
*	PP-JR15	15' DISCHARGE HOSE	1
*	PP-JR20	20' DISCHARGE HOSE	1
*	PP-JR30	30' DISCHARGE HOSE	1

\* NOT SHOWN

